Your Xumo Remote: What the Buttons Do

The remote that comes with the Spectrum Xumo box. Find the button you are wondering about.

The buttons

- **Power** — top left. Turns the box on and off.
- **Voice** — the button with a tiny microphone picture on it. Hold it down and say what you want, like “weather channel.”
- **More** — the button with three dots. Shows extra choices for whatever is on your screen.
- **Play / pause** — pauses what you’re watching, starts it again.
- **Mute** — the speaker with an X. Sound off and on.
- **OK + arrows** — the big round pad — arrows move, OK picks.
- **Back** — curved arrow. Goes back one step.
- **Home** — little house. Main screen with all your apps.
- **Volume** — speaker button. Sound up and down.
- **Channel** — moves up and down through channels.
- **Guide** — TV listings — what’s on now and later.

> **Lost?** Press Home any time to get back to the main screen.

Questions? Call Sean: (813) 770-6082